QUICK START GUIDE

Introduction

EasyPad Junior is a MediaBook with full color screen.

Although this product is safe, please observe the information and warnings from the user manual.
The user manual is installed at the devices internal memory and can be accessed over the main menu.
Please refer to the user manual for detailed instructions and support information's.

- To open the **users manual** please tap on the manual icon you can see at the home screen to open the folder where the manuals are stored in.
- Afterwards you can find the Manuals at the internal memory.

Turning On/Off

To turn on the device, press and hold the **Power** button on the unit until you see the boot-up screen then release. It may take a few minutes to start up the system, please wait before you proceed.
To turn off the device, press and hold the **Power** button until you see the option "Power Off", tap on "Power Off" and then tap on "OK".

Tip: *This device will sleep with the screen off if it stays inactive for a few seconds. You can briefly press the* ***Power*** *button to turn on the screen and wake it up.*

Power On and Off the Display

- Shortly press the [Power] button to turn off the display.
- Press the [Power] button again shortly turn the display on again.

Language Setting

- Press [Menu] button to call out the Option Menu.
- Tap on [Settings] and select [Language & Keyboard]
- Tap on [Select Language] and select your desired language.

Getting Started

1. **7" resistive TFT Screen** — You can operate on the screen using your finger or a stylus
2. **Speaker**
3. **Web Camera**
4. **Menu button** — Note: When you tap the Menu key from within an application, you will see the options for that application. To view the Android system options, tap the Menu key from the home screen.
5. **Back button** — Tap to return to the previous screen. If the keyboard is on the screen, tap to close the keyboard.
6. **Volume +**
7. **Volume -**
8. **Power Key** — Press to turn on/off your tablet
9. **Headphone jack**
10. **Reset pin hole** — Press to reset the tablet if it freezes or otherwise behaves abnormal. (Use a paperclip or other small object to gently press this key.)
11. **Mini USB port**
12. **Micro SD Card Slot**
13. **Microphone**
14. **Mini-USB Host** — A USB adapter is needed to support USB stick, Surf stick, KeyBoard and Mouse
15. **Power jack (DC input)**

Charging Battery

The device has a built-in rechargeable battery. No extra battery installation is required. Just charge the device when it indicates low battery.
To charge the battery, connect the device to any standard wall outlet via the DC-IN port using the power adaptor. It takes about 5 hours to fully charge the battery.

Note:

a. You can operate the device even when it is being charged. But for extended battery life, it is suggested NOT to use the device when it is charging.
b. It is recommended to charge the battery before you use the device for the first time.
c. For maximum performance, lithium-ion batteries need to be used often. If you don't use the device often, be sure to recharge the battery at least once per month.
d. Should the rechargeable battery of the device discharge completely, connect the device (using the adapter) to the main power source for approximately 5-10 minutes before attempting normal operation.
e. In some cases, devices which have been charged for longer periods of time may not be able to be switched back on.

Should this occur, press the RESET switch.

Installing Memory Card

This device can read files directly from memory card or USB memory.
To use a memory card, find the card slot at the side of the device and then insert the memory card into the slot in the correct orientation or Connect USB Memory using the provided USB adaptor cable.

To access the files stored in the memory card, enter the **Explorer** mode by tapping the Explorer icon and select the "Micro SD Card" directory.

- Check that the Micro SD card is in the correct position with the contact pin facing downwards as illustrated. You may damage the card and the reader if SD card is not inserted in correct position.
- Push the Micro SD card into the card slot until it clicks.
- To remove Micro SD card, push the Micro SD card once again until it clicks.

Note: *We recommend using only Micro SD or Micro SDHC cards up to 32GB capacity.*
- When a Micro SD card is inserted in or ejected from the device, it may take few seconds for the device to update the content.
- Please avoid inserting or ejecting Micro SD card when other operation is running as this may cause the system hang.
- Do Not remove the card if the content inside the card is being played. This will halt the operation of the device and might cause a system hang.
- Only use the provided USB adaptor cable to attach USB memory devices.
- Please use your fingernails to properly insert or remove the Micro SD card.

Transferring Files

Before reading or playing files, you need to transfer media files from a computer to the device.

(1) Connect the device to a computer with the supplied USB cable and tap on "Turn on USB storage
(2) Once connected, two removable disk drives will show on your computer. One represents the internal memory of the device, and the other represents the memory card inserted into the device. Now you can copy files from or to these disk drives just as you would on your hard drive
(3) Choose "Turn off USB Storage" and then tap "Turn Off" to disconnect the device from computer
(4) Disconnect the device from the PC safely.
   a) Left-click the icon at the right bottom corner of the computer desktop.
   b) Click the pop-up mini-window message of "Stop the USB Mass Storage Device – Drive (X).
   c) Disconnect the device from the computer.

Note: *The pre-installed applications and Android OS occupy a considerable part of capacity – nearly more than 1GB, it is normal that you see huge difference between available memory space and total capacity.*
Caution! The device supports Adobe DRM contents. Adobe Digital Editions (ADE) is required. Please refer to the user's manual for closer information's on how to use DRM protected files.

Screen lock

The screen automatically turns off and locks itself after a set period of time.
When the screen turned off, press the **Power** or [Home] button to light up the screen.



Push the lock icon and drag it in arrow direction to unlock.
Push the speaker icon and drag it in arrow direction to disable the sound output.

Open source

Open Source Code:
http://www.easypix.info/download/easypad_junior/ep_junior_open_source.zip

GNU General Public License:
http://www.gnu.org/licenses/gpl-2.0.html

Home Screen

α. Home soft key	Tap to return to the home screen. Tap and hold to view a list of recently used applications; touch an application in the list to launch it.
β. System Hints	Informs the user if attached memory or updates are available and other system status information's
χ. Wifi	Appears when a wireless connection was established
δ. Battery Charge	
ε. Current Time	
φ. Volume Control	Press to decrease/increase the volume level.
γ. Back soft key	Tap to return to the previous screen. If the keyboard is on the screen, tap t close the keyboard.
η. Menu soft Key	Tap to view the option menu *Note: When you Tap the Menu key from within an application, you will see the options for that application. To view the Android system options, tap th Menu key from the home screen.*
ι. Google Search Bar	
φ. Video	Video playback
κ. Aldiko	To read and manage e-books in ePub or PDf format
λ. Galerie	Picture view
μ. Browser	Tap to launch the Browser to visit your favorite websites.
ν. E-Mail	To open the mail client
ο. Applications icon	Tap on this icon to reveal all applications installed on your Tablet - You can copy the applications onto the Home screen by pressing and holding on their icons. - You can delete the application from the Home Screen by dragging their icons to the Application Tab. To delete a Home screen item, hold your finger onto it until it is highlighted, then drag it to the Application Tab which has become a trash icon.

The detail user's manual is on the EasyPad Junior!

rk29sdk_gpl_kernel_20110702

Copyright © Rockchips

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License, version 2, as published by the Free Software Foundation.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License, version 2, for more details.

You should have received a copy of the GNU General Public License, version 2, along with this program; if not, write to the Free Software Foundation, Inc., 51 Franklin St, Fifth Floor, Boston, MA 02110, USA

You should receive a complete machine-readable copy of the corresponding source code of this program under the following
link: http://www.easypix.eu/download_easypad.html

if not, write to Easypix, Corinne Loose, Em Parkveedel 11, D-50733 Cologne, Germany, e-mail: support@easypix.eu